

## POWDER WEDGE INSTRUCTIONS

- 1. Remove the stock rail tip protectors from your 2010-2013 SKI-DOO Summit. It is not necessary to remove the skid.**
- 2. Remove screw from hyfax, by locating an open window in the track to access screw head.**
- 3. Install Powder Wedge and loosely bolt both screws before completely tightening, Tighten both rail protector bolt, and hyfax screw to 60inch LB of torque.**
- 4. Enjoy your easier approach angle as you are shredding through the powder.**

**-----Note to self- Though they work fine on trail, the real benefit is the improved approach angle in powder. Some additional noise from the track slapping the edges of the powder wedge may be heard during use on trails. This is normal.**